

Product Data Sheet

Digital Timer / Count-up
Reference 91500-016/F

Specifications

- Count-down 23H-59M-59S
- Count-up 23H-59M-59S
- Large display
- 80 dB sound alarm
- Free standing
- 1 AAA battery
- In French Cooking blister



Instructions

TIMER ⌚

Press [HOUR] [MIN] [SEC] to set the desired time. Hold buttons for fast setting. Press [ST/SP] to start countdown. When timer reaches 00:00:00, the alarm will ring for 1 min. Press any button to stop the alarm. Press and hold [ST/SP] button for 3 seconds to reset.

STOPWATCH 🕒

Press [ST/SP] button to start count-up. Press again to pause or stop the count-up. Press and hold [ST/SP] button for 3 seconds to reset.



*Do not use in oven or in microwave oven . Do not wash in a dishwasher .
If the display becomes dim, replace the battery .*

Alla France

Z.I. du Bompas - 13, rue du Bompas - Chemillé - 49120 Chemillé-en-Anjou - FRANCE
Tél. + 33 (0)2 41 30 55 08 - Fax +33 (0)2 41 30 34 67

www.allafrance.com


France