

# Product Data Sheet

Mini Barista Timer  
Reference 91500-020/F

## Specifications

- Count-down 99M-59S
- Count-up 99M-59S
- 70 x 53 mm
- Jumbo display
- Backlight
- 80dB sound
- Magnet
- LR54 battery
- In French Cooking blister



## Instructions

### TIMER FUNCTION

Press [MIN] and [SEC] to set the countdown time. Press [START] to start the countdown. The timer rings when it displays "00.00". Press [STOP] to stop the alarm.

### COUNT-UP FUNCTION

Press [START] when the display is at "00.00" to activate the count up. Press again to stop it. Press [RESET] to return to "00.00".



*Do not use inside oven or microwave oven. Do not wash in a dish washer.  
If the display becomes dim, replace the battery.*

Alla France

Z.I. du Bompas - 13, rue du Bompas - Chemillé - 49120 Chemillé-en-Anjou - FRANCE  
Tél. + 33 (0)2 41 30 55 08 - Fax +33 (0)2 41 30 34 67

[www.allafrance.com](http://www.allafrance.com)

  
France