Product Data Sheet

Digital Thermo-Hygrometer With Clock

Reference 91000-005/B

Specifications

- -20+50°C / -4+122°F / 10-99% RH
- Display resolution: 0.1° / 1% RH
- Accuracy:
 ±1°C / ±2°F / ±5% RH between 30 and 70%

Clock function:

12/24H

Thermometer functions:

MAX/MIN - Alarm

Hygrometer functions:

- MAX/MIN INT
- Free standing
- 130 x 102 x 25 mm
- 2 LR03 AAA batteries
- In BIOTEMP blister, with instructions



Instructions

SETTING TIME & DATE (on the back)

Hold the [MODE] button for 2 seconds: the minute digits start flashing. Press [ADJ] until the right number is reached. Press [MODE] and adjust the hours using the [ADJ] button. Press [MODE] and use [ADJ] to change the time format (12/24 h). Press [MODE] and adjust the date using the [ADJ] button.

SETTING ALARM CLOCK (on the back)

Press [MODE] and then hold the button until the minute digits start flashing and the icon sis displayed. Press [ADJ] until the right number is reached. Press [MODE] and adjust the hours using the [ADJ] button. Press [MODE] to confirm the alarm. To dismiss it, press [MODE] once and [ADJ] 3 times (until the icon disappears). If the icon sis displayed, the device will beep at the start of every hour.

MAX/MIN MEMORY FUNCTION (on the back)

Press [MAX/MIN] to display the maximum and minimum temperatures registered since the last reset. Hold the button for 2 seconds to delete the records.

ADDITIONAL INFORMATION

- Press [°C/°F] to change the temperature unit.
- If the temperature or humidity measured is out of range, the "HH.H" or "LL.L" error code will be displayed.



Do not use inside oven or microwave oven. Do not wash in a dish washer. If the display becomes dim, replace the batteries.

Alla France

Z.I. du Bompas - 13, rue du Bompas - Chemillé - 49120 Chemillé-en-Anjou - FRANCE Tél. + 33 (0)2 41 30 55 08 - Fax +33 (0)2 41 30 34 67

